Stratus LED Recessed Light

INSTALLATION INSTRUCTIONS


aspectLED

Safety Instructions

IMPORTANT: Read all instructions before installing fixtures. Keep these instructions for future reference.

1. For your safety, this fixture must be wired in accordance with the NEC and local electrical codes and ordinances. All work should be done by a qualified electrician.
2. Make sure the power is OFF from the electrical panel before starting installation or attempting any maintenance.
3. There are no user-servicable parts inside. To avoid electrical shock, DO NOT disassemble product. Give us a call at **888.503.1317** or send us a message at **support@aspectLED.com** for troubleshooting help.
4. Do not make or alter any open holes in an enclosure of wiring or electrical components during product installation.
5. To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or sharp objects.
6. Product is suitable for damp locations.

FIG. 1



Hole Cut Size	
2 inch Downlight	2-1/8" (55 mm)
	2-1/8" × 2-1/8" (55 mm × 55 mm)
3 inch Downlight	2-15/16" (75 mm)
	2-15/16" × 2-15/16" (75 mm × 75 mm)

FIG. 2




FIG. 3




FIG. 4




FIG. 5





FIG. 1



Hole is cut and ready for install.

FIG. 2




FIG. 3





FIG. 4



Mud, Sand & Paint over drywalling ring




FIG. 5




FIG. 6




FIG. 7







FIG. 8



Replace the Bracket



Replace the Frosted Diffuser



Install the Leaf Spring

